





Unit power supply



Comand to turn on



Cable connection to the unit



- * Use data sheet to calculate the cross-sectional area of wires
- ** The type of terminals depends on the modification of the unit

OA33x/OA53x/OC33x/OC53x

Date 15.06.2017

Electrical Connection Diagram

OSTROV

www.ostrovcomplete.com